
ICU Volume 13 - Issue 4 - Winter 2013/2014 - Cover Story: Severe Pulmonary Infections Prevention of Ventilator-Associated Pneumonia (Matthieu Boisson, Olivier Mimoz)

Authors



Matthieu Boisson, MD

Chief Resident of Department of Anesthesiology and Intensive Care, University Hospital of Poitiers Poitiers, France

Inserm U1070, Faculty of Medicine and Pharmacy University of Poitiers, Poitiers, France

matthieu.boisson@chu-poitiers.fr



Olivier Mimoz, MD, PhD

Co-Head Department of Anesthesiology&Intensive Care

University Hospital of Poitiers Poitiers, France

Inserm U1070, Faculty of Medicine and Pharmacy, University of Poitiers, Poitiers, France

Introduction

Healthcare-associated infections have become a challenge in public health policy. In critically ill patients, ventilator-associated pneumonia (VAP) is the most frequent healthcare-associated infection. Depending on studies, 10% to 30% of ventilated patients will develop a VAP during their ICU stay (Chastre et al. 2002). VAPs account for heightened morbi-mortality, lengthened stays in intensive care and increased treatment costs. These infections also trigger a rise in the consumption of antibiotics, which favours the development of bacterial resistance. Therefore, decreasing VAP incidence must be a priority in the management of critically ill patients.

Physiopathology of VAP

Enhanced knowledge of the complex physiopathology of VAP has led to the development of effective preventive strategies (see Figure 1). Colonisation of the upper and digestive airways by micro-organisms originating in the patient or coming from another patient through cross-transmission is the predominant mechanism of initiation. Fostered and favoured by the presence of a tracheal tube, it is at the origin of tracheal colonisation through the bacterial aspiration resulting from the passage, around the tube cuff, of oropharyngeal secretions in the vicinity of the trachea and the lower respiratory tract (Kollef 2004).

General Rules

Prevention measures are primarily based on the universal principles of standard hygiene. They are meant to prevent cross transmission of pathogens. These measures include basic hygiene: alcohol-based hand rubbing, wearing gloves for one patient - one activity. Screening for carriage of methicillin-resistant *Staphylococcus aureus* (MRSA) and other multi-drug resistant bacteria according to local ecology, and the use of contact precautions should be utilised to prevent cross-contamination (Siegel et al. 2007). Staff training with regard to these measures helps to ensure respect of their application.

More recently, universal decolonisation with intranasal mupirocin and daily bathing with chlorhexidine-impregnated cloths has been shown to be more effective than screening and isolation to prevent healthcare-associated infections (Huang et al. 2013). However, the lack of impact on the incidence of non-staphylococcus infections and the risk of the development of resistance to mupirocin and/or chlorhexidine with their wide use are limitations to the generalisation of this practice.

probable reason for this reluctance resides in an ecological risk along with the potential emergence of multi-resistant bacteria (Daneman et al. 2013).

Oropharyngeal decontamination through local application of an antiseptic (chlorhexidine or povidone-iodine) for the purposes of limiting local flora represents another interesting method of VAP prevention. A metaanalysis involving 2481 patients showed some VAP diminution (Labeau et al. 2011). The benefits of chlorhexidine are more substantial in cardiothoracic surgery patients or when a high concentration (2%) is used.

Conclusion

Many specific preventive measures have been studied to reduce the incidence of VAP. The most important include oro-tracheal intubation, maintaining tube cuff pressure between 25 and 30 cmH₂O, use of a sedationanalgesia algorithm allowing for early weaning from ventilation, privileging use of non-invasive ventilation, the semi-recumbent position at 30-45°, and regular nasal and oro-pharyngeal decontamination with chlorhexidine. All these measures must be used in bundles.

Published on : Wed, 25 Dec 2013